

# Mitigating the Damaging Effects of Corrosion at Port Facilities

Presented by

Brian Pailes, Ph.D., P.E., NACE CP-3

Senior Project Manager

Vector Corrosion Services



# Outline

- Corrosion background
  - How and why does it happen
- Reinforced concrete structures
  - Deterioration process
  - Special considerations
- Steel structures
  - Deterioration process
- Corrosion mitigation solutions
  - Galvanic and impressed current cathodic protection




# Corrosion Background



# Corrosion


- Electrochemical reaction
- Requires
  - Moisture
  - Electrolyte – water or concrete
  - Metallic path – steel
- Anode
  - Where rust is formed
- Cathode
  - No section loss



# Corrosion Macro-Cell

**Cathode**

**Anode**



# Reinforced Concrete Structures



# Corrosion of Reinforced Concrete

- Concrete is naturally alkaline
  - pH of about 13
- Steel is naturally passive at this alkalinity
  - Formation of passive layer
- Passive layer can be destroyed by;
  - Chlorides
  - Carbonation



# Chloride Induced


- Chloride ions diffuse into concrete and destroy steel's passive layer
- Source of chlorides
  - Marine environments
  - De-icing salts
  - Chemical/processing plants
  - Cast into concrete
- Chlorides are not consumed in corrosion reaction, therefore, once threshold concentration reached, corrosion can occur unabated





# Chloride Concentration Threshold

- Generally accepted chloride thresholds
  - 350 ppm of **concrete**
  - 0.035% by mass of **concrete**
  - 1.5 lbs per cubic yard of **concrete**




# Carbonation

- Carbon dioxide permeates into concrete
- Reduces pH of concrete
  - $\text{CO}_2$  reacts with free lime,  $\text{Ca(OH)}_2$ , resulting in  $\text{CaCO}_3$  and  $\text{H}_2\text{O}$
- Reduced pH de-passivates steel
- Often seen when
  - Concrete permeability is high
  - Industrial sites
  - Very old structures – carbonation is a result of time and exposure



# Corrosion Induced Damage

- Damage resulting from
  - Metal section loss and
  - Formation of iron oxide (rust)
  - Expansive properties of iron oxide create tensile stresses in concrete
  - Leads to cracking, delamination, and eventual spalling




# Corrosion Induced Damage

- Conventional mild reinforcing bar
  - In most cases loss of steel section not primary concern
  - Damage to concrete becomes significant and observable prior to severe section loss
- High strength steel
  - Minor section loss can have significant effect on strength
  - Can have significant section loss without significant concrete damage



# Patch Accelerated Corrosion



# Steel Structures



# Steel Structures

- Directly exposed to environment
- Primary factors affecting corrosion
  - pH
  - Temperature
  - Moisture
    - Wetting drying cycles
  - Ion content
    - Chlorides, sulfates, etc.
  - Oxygen Content
  - Water Velocity



Source – [techknowserv.com](http://techknowserv.com)



# Dissimilar Metals – Galvanic Corrosion

- Dissimilar metals in direct electrical contact with each other will result in the less noble metal corroding
  - Principal used in galvanic cathodic protection to protect a metal while sacrificing another metal.

Table 1.1 Partial Standard emf Series of Metals

Half-cell	Metal	Standard Electrode Potential $E_o$ (volts) vs. SHE*
Au/Au <sup>+++</sup>	Gold	+1.498
Pt/Pt <sup>++</sup>	Platinum	+1.200
Cu/Cu <sup>++</sup>	Copper	+0.345
H <sub>2</sub> /2H <sup>+</sup>	Hydrogen	0.000
Pb/Pb <sup>++</sup>	Lead	-0.126
Ni/Ni <sup>++</sup>	Nickel	-0.250
Fe/Fe <sup>++</sup>	Iron	-0.440
Zn/Zn <sup>++</sup>	Zinc	-0.763
Al/Al <sup>+++</sup>	Aluminum	-1.662
Mg/Mg <sup>++</sup>	Magnesium	-2.363



\* Standard Hydrogen Electrode




# Stray Current Corrosion

- Currents through electrical paths other than the intended circuit
- Can cause rapid loss of steel
  - Dependent on amperage and affected surface area
- Commonly seen;
  - Electrified rails
  - Cathodically protect utility pipes near metal structures that are not cathodically protected



# Stray Current





# Corrosion Mitigation



# Cathodic Protection

- Cathodic protection (CP) is a method of corrosion control through the application of direct current to a metal under protection, forcing it to become a cathode
  - Anode is where rust occur and the cathode is protected from section loss
- Two main types of CP
  - Galvanic
  - Impressed current





# Impressed vs Galvanic


- Galvanic
  - Typically very low maintenance
  - Self regulating current output based on environment
    - Current output limited
  - Typically less expensive
    - Not always though
  - Limited life span – between 10 to 30 years
- Impressed
  - Provides significantly more current
    - Can reduce number of anodes
  - Long life span
    - Can be over 50 years depending on application
  - Requires maintenance



# Galvanic CP




- Uses the concept of dissimilar metal corrosion in order to protect steel reinforcing.
  - Anode types;
    - Zinc
    - Aluminum
    - Magnesium
  - All are less noble than steel




# Bent Cap Repairs

- Mitigate corrosion of a pier in the Dominican Republic






# Steel Sheet Pile Construction





# Sheet Pile Galvanic CP




# Piles



- Jacketing is the most common repair strategy
  - Critical to have cathodic protection in jackets
  - FDOT discovered accelerated corrosion in jackets without CP
    - Hartt, W.H. and Rapa, M., “Condition Assessment of Jackets Upon Pilings for Florida Bridge Substructures,” Final Report, WPI No. 0510803, Florida Department of Transportation, Tallahassee, Florida, April 13, 1998

# Galvanic CP – Pile Jackets

- Several different types of jackets
- Dependent on the environment
  - Chloride content of water
  - Tidal range




# Zinc Mesh – Tidal Jacket

- Used only in salt water environments where most of the pile length is within the tidal region
  - Requires constant exposure to salt water to keep zinc active



# Above Tidal Jacket

- Commonly referred to as “wicking” jackets
- Zinc wrapped in absorbent fabric
  - Draw salt water above tidal region to keep zinc active
- Still uses a bulk anode below the water line



# Alkali Activated Jackets

- Can be used in salt water, above tidal, brackish, freshwater, or non marine environments
  - Uses pH of mortar to activate zinc instead of salt water





# Jacket Installation



# Metalizing Both Galvanic and Impressed




20E





# Impressed Current




# Puerto Nuevo Terminal

- Sheet pile wall protected with impressed current CP system
  - No recent monitoring or maintenance of system



# Power Source



# Questions

